

Breast Cancer Awareness Bracelets

perler®



YOU WILL NEED:

Pegboards:
2 large squares

Other:
Ironing paper & iron
Rubber bands

Bead Colors:

- Light Pink - 197
- Bubblegum - 246
- Pink - 311

Instructions

1. Connect the two pegboards, then place your beads on the pegboards as shown on the next page. If you are using clear pegboards, slide the actual-size pattern underneath them.
2. Ask an adult to fuse your designs—see below.

Fusing Instructions—Only Adults Iron



1. Place your pegboard on a flat, heat-safe surface.
2. Set a household iron to the medium setting. Place ironing paper over the pegboard. In a circular motion, begin to iron the project. Do not press down with the iron. As the beads begin to fuse, you will see circles of the beads start to show through the paper. When ironed properly, the beads will still have an open center. Let the design cool.
3. Remove the paper and bead design from the peg board. Flip the design over to expose the non-fused side. Repeat step two. While still warm and with paper still in place, wrap the design around a glass to create the cuff shape. Secure with rubber bands. Let cool completely. then remove the paper.

NOTE: Beads need heat for about 10-20 seconds per side to fuse evenly. Lift the paper occasionally to see how the beads are fusing. Depending on the size of the project, additional heating time may be required.

