



YOU WILL NEED:

Pegboard:

4 Mini Beads pegboards

Other:

80-17527 Mini Beads








Neutral Tray

Mini Beads tweezers

Iron and ironing paper

Decorative clipboard with stand

Bead Colors:

-  Bubblegum - 100
-  Red - 82
-  Orange - 124
-  Cheddar - 77
-  Kiwi Lime - 217
-  Dark Green - 49
-  Toothpaste - 1618
-  Sand - 233
-  Brown - 10
-  Black - 626

Instructions

1. Slide the actual-size pattern under your clear pegboard and place your beads as shown.
2. Ask an adult to fuse your designs—see page 2 for further instructions.
3. Assembly: Place your finished design under the clip.



Fusing Instructions—Only Adults Iron



1. Place your pegboard on a flat, heat-safe surface.
2. Set a household iron to the medium setting. Place ironing paper over the pegboard. In a circular motion, begin to iron the project. Do not press down with the iron. When ironed properly, the beads will still have an open center. Let the design cool.
3. Remove the paper and bead design from the pegboard. Flip the design over to expose the non-fused side. Repeat step two. Let cool completely.

Beads need heat for about 10 seconds per side to fuse evenly. Depending on the size of the project, additional heating time may be required.