







Bead Colors

 Cotton Candy	x 19	 Toothpaste	x 5
 Tomato	x 31	 Plum	x 45
 Cherry	x 11	 Purple	x 6
 Pastel Yellow	x 41	 Light Gray	x 19
 Rich Butter	x 47	 White	x 76

The diagram below shows how to open the jump ring with the needle nose pliers. Twist the ends in opposite directions; don't pull outward to separate the ends. After sliding the jump ring through the opening in the top of the design and the keychain, use the pliers to twist the ends back together.

