








Bead Colors


 Tomato	x 917	 Sky	x 308	 Butterscotch	x 8
 Cotton Candy	x 185	 Turquoise	x 166	 Light Gray	x 4
 Salmon	x 11	 Sand	x 124	 White	x 241
 Flamingo	x 13	 Cheddar	x 86	 Black	x 268

Join the two pegboards before starting. Create the pattern below on the top pegboard, then create the pattern on page 2 on the bottom pegboard. Keep the pegboards together when ironing so that both halves fuse together. Repeat with the patterns on pages 3 and 4 to make the back of the nutcracker.

FRONT - top half



FRONT - bottom half



Ironing Instructions


Beads should be fused together with a **dry** household iron by an **adult** only. Please keep children at a safe distance.

1. Place pegboard on flat, heat-safe surface.
2. Set iron to medium. Place ironing paper over beads and pegboard. Using a circular motion, iron for about 10-20 seconds. Do not press down on the iron. When ironed properly, beads will still have an open center. Let cool.
3. Remove ironing paper and bead design from pegboard. Flip design over to expose the non-fused side. Place ironing paper over design and iron again. To prevent bead design from warping, place a heavy book on design as it cools.


Note: Do not place iron directly against beads or pegboard. Pegboard is not designed for use in any type of oven; it will warp.

Pegboard and ironing paper are reusable.

BACK - top half




BACK - bottom half




CONNECTORS make 2 of each

HANDLE



BASE make 2

Use the connectors to join the two layers.



Insert the nutcracker into the base.



Add the handle to the back of the nutcracker.

