Fidget Spinners





YOU WILL NEED:

Pegboard:

Large hexagon

Other:

Iron and ironing paper Tweezers Hot glue gun

Hardware per spinner:

Three 3/8" stainless steel hex nuts One steel ball bearing: 8 x 22 x 7mm

Bead Colors:

Pink Candy Stripe - 54

Pink - 23

Blush - 23

Hot Coral - 23

Prickly Pear - 23

Kiwi Lime - 23

Toothpaste - 23

Sky Blue Stripe - 54

Red - 23


Zebra Stripe - 54

Black - 23


White - 23

Instructions

- If you are using a clear pegboard, slide the actual-size pattern underneath it. Place your beads on the pegboard as shown.
- 2. Ask an adult to fuse your designs—see page 3 for further instructions.
- 3. Assembly: An adult should do this step.
 Use the hot glue gun to secure the ball bearing in the center open space, and a hex nut in each of the three outer open spaces. Then, spin away!







Bead Colors:


Pink Candy Stripe

Pink

Blush

Hot Coral





Bead Colors:

Red

Zebra Stripe

Black

White

Fusing Instructions—Only Adults Iron



- 1. Place your pegboard on a flat, heat-safe surface.
- 2. Set a household iron to the medium setting. Place ironing paper over the pegboard. In a circular motion, begin to iron the project. Do not press down with the iron. As the beads begin to fuse, you will see circles of the beads start to show through the paper. When ironed properly, the beads will still have an open center. Let the design cool.
- 3. Remove the paper and bead design from the peg board. Flip the design over to expose the non-fused side. Repeat step two. Let cool completely. Your pegboard and ironing paper are reusable.

NOTE: Beads need heat for about 10-20 seconds per side to fuse evenly. Lift the paper occasionally to see how the beads are fusing. Depending on the size of the project, additional heating time may be required.