



George Washington



Benjamin Franklin



Abraham Lincoln



Alexander Hamilton



Thomas Jefferson


YOU WILL NEED:

Pegboards:
2 large squares

Other:
Iron and ironing paper
Tweezers

Bead Colors:

-  Sand - 443
-  Blush - 8
-  Cranapple - 102
-  Cheddar - 57
-  Butterscotch - 51
-  Gold Metallic - 17
-  Toothpaste - 12
-  Evergreen - 36
-  Light Blue - 14
-  Dark Blue - 154
-  Tan - 110
-  Light Brown - 120
-  Brown - 67
-  Light Grey - 43
-  Grey - 104
-  Dark Grey - 28
-  Black - 587
-  White - 227



Instructions

1. For all but Benjamin Franklin, assemble the two pegboards vertically. If you are using a clear pegboards, slide the actual-size pattern underneath them. Place your beads on the pegboards as shown.
2. Ask an adult to fuse your designs—see page 5 for further instructions.
3. Add the footstands by sliding them on the feet at right angles.


ALEXANDER HAMILTON



Bead Colors:


-  Sand
-  Cheddar
-  Gold Metallic
-  Evergreen
-  Tan
-  Light Brown
-  Light Grey
-  Grey
-  Black
-  White

THOMAS JEFFERSON




- Bead Colors:**
-  Sand
 -  Cranapple
 -  Cheddar
 -  Butterscotch
 -  Gold Metallic
 -  Dark Blue
 -  Light Brown
 -  Brown
 -  Light Grey
 -  Black
 -  White

ABRAHAM LINCOLN



- Bead Colors:**
-  Sand
 -  Gold Metallic
 -  Tan
 -  Light Brown
 -  Black
 -  White

BENJAMIN FRANKLIN



Bead Colors:

-  Sand
-  Cranapple
-  Cheddar
-  Gold Metallic
-  Toothpaste
-  Dark Blue
-  Brown
-  Light Grey
-  Grey
-  Dark Grey
-  Black
-  White

Fusing Instructions—Only Adults Iron



1. Place your pegboard on a flat, heat-safe surface.
2. Set a household iron to the medium setting. Place ironing paper over the pegboard. In a circular motion, begin to iron the project. Do not press down with the iron. As the beads begin to fuse, you will see circles of the beads start to show through the paper. When ironed properly, the beads will still have an open center. Let the design cool.
3. Remove the paper and bead design from the peg board. Flip the design over to expose the non-fused side. Repeat step two. Let cool completely.

NOTE: Beads need heat for about 10-20 seconds per side to fuse evenly. Lift the paper occasionally to see how the beads are fusing. Depending on the size of the project, additional heating time may be required.