



YOU WILL NEED:

Pegboard:

Large square

Other:

Cardstock: green, light pattern










Tape runner

Quick-drying adhesive

Ribbon: 1/8" red, 3/8" decorative red


Clear adhesive dots

Bead Colors:

-  Peach - 3
-  Hot Coral - 10
-  Red - 14
-  Cranapple - 9
-  Kiwi Lime - 78
-  Green - 82
-  Dark Green - 146
-  Clear - 16
-  Prickly Pear Pearl Stripe - 64


Instructions

1. Place your beads on the pegboards as shown. If you are using a clear pegboard, slide the actual-size pattern underneath it.
2. Ask an adult to fuse your designs—see page 2 for further instructions.
3. Assembly: see page 2.



Under my Mistle-Toes for you

- 1 Lace the thin ribbon through the indicated beads to hold the ornament. Attach the berries to the feet with quick-drying adhesive. Add a bow over the berries.



- 2 To make the card, cut a 6" x 12" piece of green cardstock and fold in half for a top-folding card. Cut the patterned paper to 5 1/2" x 5 1/2" and attach to the center of the card front with the tape runner.
- 3 Position your Mistle-Toes ornament as shown in the photo and attach it with clear adhesive dots. This will enable the design to be detached and used as an ornament by the one receiving the card.
- 4 Print page 1 and cut out the holiday message. Attach to the card front with the tape runner.

Fusing Instructions—Only Adults Iron



1. Place your pegboard on a flat, heat-safe surface.
2. Set a household iron to the medium setting. Place ironing paper over the pegboard. In a circular motion, begin to iron the project. Do not press down with the iron. As the beads begin to fuse, you will see circles of the beads start to show through the paper. When ironed properly, the beads will still have an open center. Let the design cool.
3. Remove the paper and bead design from the peg board. Flip the design over to expose the non-fused side. Repeat step two. Let cool completely.

NOTE: Beads need heat for about 10-20 seconds per side to fuse evenly. Lift the paper occasionally to see how the beads are fusing. Depending on the size of the project, additional heating time may be required. DO NOT OVER-IRON the beads as it will make the centers of the beads close and can make the assembly you do with your project more challenging.