




YOU WILL NEED:

Pegboards:	Bead Color/# Needed:
2 large squares	<ul style="list-style-type: none"> ● Blush - 53 ● Light Green - 115 ● Turquoise - 60 ● Pastel Lavender - 30 ● Purple - 44 ● Grey - 78 White - 813

You will also need clear-drying adhesive to complete your project.


Instructions

1. Place your beads on the pegboards as shown. If you are using a clear pegboard, slide the actual-size pattern underneath it.
2. Ask an adult to fuse your designs—see Fusing Instructions on page 3.
3. **Assembly:** see page 3.



Bead Color:

- Blush
- Turquoise
- Pastel Lavender
- Purple
- Grey
- White




Join two large square pegboards side by side as shown. Cut out the pattern on page 3 and tape it to the right of the one below, aligning the edges exactly.

Now place the beads for all of the hull pieces.

HULL
PIECES



Hull 1

Hull 2



Bead Color:

-  Light Green
-  White



- ASSEMBLY:**
1. Glue these layers together in order from top to bottom, centering them on each other:
Deck
Hull 1
Hull 2
Hull 3
Hull 4
 2. Glue the cockpit near the stern end of the deck (opposite of the pointy end).
 3. Insert the bottom of the mast in the opening in the deck.

Fusing Instructions—Only Adults Iron



1. Place your pegboard on a flat, heat-safe surface.
2. Set a household iron to the medium setting. Place ironing paper over the pegboard. In a circular motion, begin to iron the project. Do not press down with the iron. As the beads begin to fuse, you will see circles of the beads start to show through the paper. When ironed properly, the beads will still have an open center. Let the design cool.
3. Remove the paper and bead design from the peg board. Flip the design over to expose the non-fused side. Repeat step two. Let cool completely.

NOTE: Beads need heat for about 10-20 seconds per side to fuse evenly. Lift the paper occasionally to see how the beads are fusing. Depending on the size of the project, additional heating time may be required. **DO NOT OVER-IRON** the beads as it will make the centers of the beads close and can make any assembly you do with your project more challenging.