




YOU WILL NEED:

Pegboard:
Large square

Other:
Iron and ironing paper
Tweezers
Bottle or glass with a
3" diameter
Rubber bands


Bead Colors:
● Yellow - 282
● Cheddar - 142
● Light Brown - 694
● Brown - 559
● Black - 11



Instructions


1. If you are using a clear pegboard, slide the actual-size pattern underneath it. Place your beads on the pegboards as shown.
2. Ask an adult to fuse your designs—see page 3 for further instructions.
NOTE: Immediately after fusing the lid piece **ON ONE SIDE ONLY** and while the beads are still warm, wrap the piece around a bottle or glass with the fused side in, and hold it in place with rubber bands until cool.
3. **ASSEMBLY:** Press the sides to the front and back pieces, aligning tabs with slots. Press the bottom onto the chest.
When the curved lid piece is cool, place it over the assembled box. Now you're ready to stow away your booty!

Sides




Bottom

- Bead Colors:**
- Yellow
 - Cheddar
 - Light Brown
 - Brown



Lid



- Bead Colors:**
-  Yellow
 -  Cheddar
 -  Light Brown
 -  Brown

Fusing Instructions—Only Adults Iron



1. Place your pegboard on a flat, heat-safe surface.
2. Set a household iron to the medium setting. Place ironing paper over the pegboard. In a circular motion, begin to iron the project. Do not press down with the iron. As the beads begin to fuse, you will see circles of the beads start to show through the paper. When ironed properly, the beads will still have an open center. For all pieces but the lid, let the design cool, then proceed to step 3. **For the lid, stop here and immediately wrap the piece around a bottle or glass with the fused side in and hold in place with rubber bands. Let the design cool.**
3. Remove the paper and bead design from the peg board. Flip the design over to expose the non-fused side. Repeat step two. Let cool completely.

NOTE: Beads need heat for about 10-20 seconds per side to fuse evenly. Lift the paper occasionally to see how the beads are fusing. Depending on the size of the project, additional heating time may be required. **DO NOT OVER-IRON** the beads as it will make the centers of the beads close and can make the assembly you do with your project more challenging.